

# MB452 DRIVER スリーブ位置変化表

LOFT 9.5°

LOFT	10.0°
LIE	61.0°
F/A	H1.0

LOFT	9.5°
LIE	61.5°
F/A	0

LOFT	9.0°
LIE	61.0°
F/A	S1.0

U

LOFT	10.5°
LIE	60.5°
F/A	H2.0

+



LOFT	8.5°
LIE	60.5°
F/A	S2.0

N

LOFT	10.0°
LIE	60.0°
F/A	H1.0

LOFT	9.5°
LIE	59.5°
F/A	0

LOFT	9.0°
LIE	60.0°
F/A	S1.0

# MB452 DRIVER スリーブ位置変化表

LOFT 10.5°

LOFT	11.0°
LIE	61.0°
F/A	H1.0

LOFT	10.5°
LIE	61.5°
F/A	0

LOFT	10.0°
LIE	61.0°
F/A	S1.0

U

LOFT	11.5°
LIE	60.5°
F/A	H2.0

+

LOFT	9.5°
LIE	60.5°
F/A	S2.0



N

LOFT	11.0°
LIE	60.0°
F/A	H1.0

LOFT	10.5°
LIE	59.5°
F/A	0

LOFT	10.0°
LIE	60.0°
F/A	S1.0

# MB452 DRIVER スリーブ位置変化表

LOFT 11.5°

LOFT	12.0°
LIE	61.0°
F/A	H1.0

LOFT	11.5°
LIE	61.5°
F/A	0

LOFT	11.0°
LIE	61.0°
F/A	S1.0

U

LOFT	12.5°
LIE	60.5°
F/A	H2.0

+

LOFT	10.5°
LIE	60.5°
F/A	S2.0

N

LOFT	12.0°
LIE	60.0°
F/A	H1.0

LOFT	11.5°
LIE	59.5°
F/A	0

LOFT	11.0°
LIE	60.0°
F/A	S1.0